



NOTES: 1. USE INSTRUCTION SHEET IN9110 FOR ATTACHING DAK TO PXI CARD. 2. MATING ITA MODULE P/N 561401. 3. SUPPLIED WITH MOUNTING HARDWARE. 4. SEE SHEET 3 FOR WIRE LIST. MAC 561301 **Banana Plugs** PXI-4022 **J1** S1 Blue S2 Black S3 Red S4 Black S5 Red MAC PANEL PROPRIETARY 14/04/2009 AO ENGINEERING MAC PANEL COMPANY - HIGH POINT, NC This document may contain confidential and proprietary information that is the property of MAC Panel Company that may not be disclosed to, or duplicated for others GAC OPERATIONS except as authorized by MAC Panel Company C.BOGGS TOLERANCES (UNLESS OTHERWISE SPECIFIED) BALLOON LEGEND MANUFACTURING DAK ASSY, SCOUT, PXI-4022 R.SPIVEY ASSEMBLY SHEET METAL Third Angle Projection ANGLES ± 1' ANGLES ± 1' PART NUMBER DWG NO MATERIAL USED QTY 561141-cu SCALE REMOVE ALL BURRS AND BREAK SHARP EDGES. 1/1 SPN: SIMILAR P/N SHEET 3 OF 3