


COMMENTS / NOTES

Module fitting procedure:

Top is removed by unscrewing 3 screws ("a") with a $\frac{7}{64}$ " Hex key. The ITA module can then be fastened into position, wires routed through the clamp mechanism and the top replaced.



WWW.MACPANEL.COM



OF

ITA, MPX, Backshell, Integrated clamp strain relief.

302000-19-CU

