

COMMENTS / NOTES

Micro Power OR Micro Coax Contacts.  
 Positions: (1 ↔ 4) (9 ↔ 12) (17 ↔ 20) (25 ↔ 28)  
 Signal Contacts.  
 Positions: (5 ↔ 8) (13 ↔ 16) (21 ↔ 24) (29 ↔ 32)




WWW.MACPANEL.COM

DRAWN BY  
shodnett

DATE  
10/17/2013

DESCRIPTION

Hybrid LIF, 16 / 16 Plug



SHEET  
1 OF 1

DRAWING NO.

Lif-16-16-M-CU

REVISION

B