

SCOUT ITA to Receiver Engagement Instructions









Before engaging the ITA with the receiver for the first time or after a long period ensure that all modules are correctly positioned and aligned with the correct mating version, Also ensure that there is no debris or loose parts that can interfere with proper engagement.



2: After inspection ensure that the Receiver Handle is in the up or closed position and then place the ITA onto the hangers.







5: Always protect the contacts of both the ITA and the Receiver when the units are not engaged. MAC Panel strongly suggests the use of protective covers for this purpose.



- Before engaging the ITA with the receiver for the first time or after a long period ensure that all modules are correctly positioned and aligned with the correct mating version, Also ensure that there is no debris or lose parts that can interfere with proper engagement.
- After inspection ensure that the Receiver Handle is in the up or closed position and then place the ITA onto the hangers.
- 3: Open the receiver handle fully and then move the ITA as squarely as possible to the receiver front face as far as the mechanism allows.
- 4: Keeping the ITA square to the receiver front face rotate the handle up until it locks. The Receiver mechanism will move the ITA into the closed position.
- 5: Always protect the contacts of both the ITA and the Receiver when the units are not engaged. MAC Panel strongly suggests the use of protective covers for this purpose.

To disengage the ITA reverse this procedure.