




NOTES:

1. USE INSTRUCTION SHEET IN91100 FOR ATTACHING DAK TO PXI CARD.
2. RECEIVER/ITA MODULE TO BE KEYPED ON LEFT SIDE.
3. WAITING ITA MODULE P/N 561413.
4. SUPPLIED WITH MOUNTING HARDWARE.
5. SEE SHEET 3 FOR WIRE LIST.



RIGHT SIDE PLATE REMOVED FOR CLARITY.

DRAWN BY WJKM ENGINEERING M4		13/04/2007	MAC PANEL COMPANY - HIGH POINT, NC	
OPERATIONS C. BOGGGS		13/04/2007	TITLE	
MANUFACTURING R. SPIVEY		13/04/2007	DAK ASSY, SCOUT, 68 PIN HONDA	
ASSEMBLY			SIZE C	DWG NO 561056-CU
MATERIAL USED			SCALE 1/1	SPR: SIMILAR P/N
				SHEET 1 OF 3


<p>MAC PANEL PROPRIETARY</p> <p>This document may contain confidential and proprietary information that is the property of MAC Panel Company that may not be disclosed to, or duplicated for others except as authorized by MAC Panel Company.</p>		<p>Third Angle Projection</p>
<p>TOLERANCES (UNLESS OTHERWISE SPECIFIED)</p>		
SHEET METAL	MACHINED	
ANGLES ± 1°	ANGLES ± 1°	
± .03	± .01	
.XX	.XX	
.XXX	.XXX	
	.0005	
	± .0005	
REMOVE ALL BURRS AND BREAK SHARP EDGES.		

BALLOON LEGEND	PART NUMBER
	QTY

NOTES:

1. USE INSTRUCTION SHEET IN91100 FOR ATTACHING DAK TO PXI CARD.
2. RECEIVER/ITA MODULE TO BE KEYPED ON LEFT SIDE.
3. WAITING ITA MODULE P/N 561413.
4. SUPPLIED WITH MOUNTING HARDWARE.
5. SEE SHEET 3 FOR WIRE LIST.



DRAWN BY WJKM ENGINEERING M4		13/04/2007	MAC PANEL COMPANY - HIGH POINT, NC					
OPERATIONS C. BOGGS		13/04/2007	TITLE					
MANUFACTURING R. SPIVEY		13/04/2007	DAK ASSY, SCOUT, 68 PIN HONDA					
ASSEMBLY			SIZE C	DWG NO 561056-CU				
MATERIAL USED -			SCALE 1/1	SPRN: SIMILAR P/N				
<p>MAC PANEL PROPRIETARY</p> <p>This document may contain confidential and proprietary information that is the property of MAC Panel Company that may not be disclosed to, or duplicated for others except as authorized by MAC Panel Company.</p> <p>Third Angle Projection</p>				SHEET 2 OF 3				
<p>TOOLERANCES (UNLESS OTHERWISE SPECIFIED)</p> <p>SHEET METAL MACHINED</p> <p>ANGLES ± 1°</p> <p>± .03</p> <p>.XX ± .05</p> <p>.XXX ± .010</p> <p>± .005</p> <p>± .0005</p> <p>REMOVE ALL BURRS AND BREAK SHARP EDGES.</p>								
<p>BALLOON LEGEND</p> <table border="1"> <thead> <tr> <th>PART NUMBER</th> <th>QTY</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> </tbody> </table>		PART NUMBER	QTY					
PART NUMBER	QTY							

NOTES:

1. USE INSTRUCTION SHEET IN91100 FOR ATTACHING DAK TO PXI CARD.
2. RECEIVER/ITA MODULE TO BE KEYPED ON LEFT SIDE.
3. WAITING ITA MODULE P/N 561413.
4. SUPPLIED WITH MOUNTING HARDWARE.
5. SEE SHEET 3 FOR WIRE LIST.

561056WL				
MAC %6 PIN CONNECTOR	68 PIN SCSI CONNECTOR	MAC %6 PIN CONNECTOR	68 PIN SCSI CONNECTOR	68 PIN SCSI CONNECTOR
A2	2	B1	35	C1
A4	3	B2	4	C2
A5	38	B4	5	C4
A6	39	B5	40	C5
A8	8	B6	41	C6
A9	9	B8	10	C8
A10	44	B9	11	C9
A12	45	B10	46	C10
A13	14	B12	47	C12
A14	15	B13	16	C13
A16	50	B14	17	C14
A17	51	B16	52	C16
A18	20	B17	53	C17
A20	21	B18	22	C18
A21	56	B20	23	C20
A22	57	B21	58	C21
A24	26	B22	59	C22
A25	27	B24	28	C24
A26	62	B25	29	C25
A28	63	B26	64	C26
A29	65	B28	31	C28
A30	34	B29	66	C29
		B30	67	C30
				68

<p><b>BALLOON LEGEND</b></p> <p>PART NUMBER</p> <p>QTY</p>	<p>MAC PANEL PROPRIETARY</p> <p>This document may contain confidential and proprietary information that is the property of MAC Panel Company that may not be disclosed to, or duplicated for others except as authorized by MAC Panel Company.</p>	<p>DRAWN BY</p> <p>WIKM</p> <p>ENGINEERING</p> <p>M4</p> <p>OPERATIONS</p> <p>C. BOGGS</p> <p>MANUFACTURING</p> <p>R. SPIVEY</p> <p>ASSEMBLY</p> <p>MATERIAL USED</p> <p>-</p>	<p>13/04/2007</p> <p>13/04/2007</p> <p>13/04/2007</p> <p>13/04/2007</p>	<p>MAC PANEL COMPANY - HIGH POINT, NC</p>
	<p>MAC PANEL PROPRIETARY</p> <p>This document may contain confidential and proprietary information that is the property of MAC Panel Company that may not be disclosed to, or duplicated for others except as authorized by MAC Panel Company.</p> <p>TOLEANCES (UNLESS OTHERWISE SPECIFIED)</p> <p>SHEET METAL MACHINED</p> <p>ANGLES ± 1°</p> <p>± .03</p> <p>.XX ± .01</p> <p>.XXX ± .010</p> <p>± .01</p> <p>± .005</p> <p>± .0005</p> <p>REMOVE ALL BURRS AND BREAK SHARP EDGES.</p>	<p>Third Angle Projection</p>	<p>DAK ASSY, SCOUT, 68 PIN HONDA</p>	<p>SIZE</p> <p>C</p> <p>DWG NO</p> <p>561056-CU</p>